





Technical Guide W8.10

Cyble™ Sensor

Cyble technology for reliable water and gas meter data transmission

Cyble communication modules have been designed to fulfil requirements of all water and gas management utilities willing to remote read their meters. Since meters are an important investment for utilities, all Itron meters are pre-equipped considering actual or future evolutions towards remote reading technologies. Proven by several millions installed Cyble modules, this patented technology ensures reliable, remote counting.

FEATURES

The Cyble Sensor suits to various remote reading applications for residential, commercial and industrial uses. It provides:

- » LF output
 - Remote reading
 - Consumption recording
- » HF output
 - Flow analyses (datalogging)
 - Frequency/current conversion
 - Automatic control

Compatibility

The Cyble Sensor is completely compatible with all Itron water and gas meters equipped with the Cyble target. It can be easily retrofitted and installed on meters already on the field*.

No need to break or dismantle meter seal and protective cap to connect the module.

High Reliability

With the unique patented principle backflow and pulses are detected and compensated so that meter index and remote register are always identical. The integrity and reliability of this data is key for use in billing applications.

- » Equipped with anti-tampering features, Cyble modules are resistant to external magnetic influence and send out alarms in the event of unauthorised unclipping or cable cut off.
- » As the product is totally waterproof (IP68) and the detection is by change of induction the unit has been designed to withstand harsh environments and can be operate in floaded pits.
- » The Cyble Sensor is not sensible to pipe vibrations. Parasitic pulses do not disturb metering.
- » The Cyble Sensor complies with E.M.C. standards for protection against electromagnetic disturbances.

Output Signals

- » LF (low frequency)
 - The LF output is the compensated output - backflow and pipe vibrations do not generate any pulses.
 - The modules are factoryprogrammed with a K factor which, when multiplied by the HF signal, enables greater pulse weight values to be transmitted.
- » HF (high frequency)
 The HF signal detects the rotation of the Cyble target.
 HF signal = 1 pulse per revolution.
 It represents the smallest pulse weight that can be remotely transmitted.
 It remains active whenever there is a flow, whatever the flow direction is.
- » A DIR signal indicates that the HF signal corresponds to a flow of water in either the forward or reverse direction.
- » Cable cut; via a ground loop current, the condition of the cable can be monitored.

Version		2-wire	5-wire
LF signal		•	•
Cable cut detection		-	•
HF signal		-	•
Direction signal		-	•
Internal power supply (battery)		•	•
Signal output	Power supply Max. Current (mA) Max. voltage (V) Max. Power (W) Polarization Type Capacitance pF	No Open Colector 600 (w	DC 100 30 1 Yes Open Collector
Internal battery/Life time(*)		Yes, lithium battery/12 years - Not replaceable	
Length of moulded cable		5	
Number of conductors		2	5
Cable dimensions		6.6 x 2.3 round cable	
Conductor diameter		0.9	
Working temperature		-10/+55	
Storage temperature		-20/+55	
Protection		IP68	
E.M.C. standards		EN 50081-1, EN 50081-2, EN 50082-1, EN 50082-2	
K factor LF = HF multiplied by K		K = 1 / 2.5 / 10 / 25 / 100 / 1000	
(*) Under normal applications within the specified working temperature range.			




Water meter equipped with cyble sensor module




Gas meter equipped with cyble sensor module

CONNECTIONS

(**) Typical value = 100pF/meter







» 5-wires

Important Note:

The fast duration of the pulse does not allow to connect electro-mechanical relays.

SPECIAL FEATURES

2-wires

- No polarity to be observed.
- The signal is equivalent to a dry contact signal (e.g. reed switch).

5-wires

- Polarities must be observed for eachoutput.
- All signals have a positive value in relation to 0 V (black).
- The HF output signals is present whenever there is flow in the meter, in either direction.
- The DIR output is off when the HF signal corresponds to the forward direction of the water.





